

RDM Series Service Manual



WARNING: This is a controlled document. It is your responsibility to deliver this information to the end user of the DESTACO CAMCO product. Failure to deliver this could result in your liability for injury to the user or damage to the machine. For copies of this manual, call your Customer Service Representative at 1-800-645-5207.

RDM SERIES

Product Sections

80RDM SERIES



601RDM, 902RDM, 1305RDM, 1800RDM SERIES



TABLE OF CONTENTS

INTRODUCTION	2
WARNING AND CAUTIONS	2
OIL SEAL REMOVAL	3
SPARE PARTS KIT	3
BEFORE STARTING	3
DISASSEMBLY	4
GENERAL	4
INPUT SHAFT PLUG AND LUBE REMOVAL	4
OPTIONAL STATIONARY OUTPUT SHAFT REMOVAL	4
OPTIONAL OUTPUT SHAFT PLUGS REMOVAL	4
OUTPUT SHAFT/FOLLOWER WHEEL REMOVAL	4
OPTIONAL THRU HOLE TUBE REMOVAL	4
INSPECTION OF CAM FOLLOWERS	4
FOLLOWER REMOVAL	5
OUTPUT SHAFT/FOLLOWERWHEEL BEARING REMOVAL	5
INPUT SHAFT/CAM REMOVAL	5
INPUT SHAFT/CAM DISASSEMBLY	5
ASSEMBLY	6
PRIOR TO REASSEMBLY	6
INPUT SHAFT/CAM REASSEMBLY	6
OUTPUT SHAFT/FOLLOWER WHEEL REASSEMBLY	6
INSTALLING NEW BEARING CUPS	6
SETTING INPUT SHAFT/CAM BEARING PRELOAD	7
OUTPUT SHAFT/FOLLOWER WHEEL INSTALLATION	7
SETTING CAM	7
OIL SEAL INSTALLATION	8
OPTIONAL THRU HOLE TUBE INSTALLATION	8
OPTIONAL STATIONARY OUTPUT SHAFT INSTALLATION	9
OPTIONAL OUTPUT SHAFT PLUGS INSTALLATION	9
LUBRICATION	9
HOW TO ORDER PARTS	10
80 RDM	11
80 RDM PARTS LIST	12

80RDM SERIES

Service Manual

INTRODUCTION

This service manual pertains to the disassembly and assembly of CAMCO's 80RDM Index Drive.

The Manual is to be used in conjunction with the General Service Manual which describes the lubrication and general maintenance of CAMCO Index Drives.

An illustration of the index drive is included in this manual. The procedures in this manual reference the item numbers of this illustration.

Also included is a complete Bill of Materials for your convenience in identifying and ordering spare or replacement parts.

Some users of index drives have the facilities and trained personnel to accomplish service repair. You must determine the extent to which intricate servicing should be done in your facility. When in doubt, CAMCO recommends that CAMCO trained serviceman make the repairs.

WARNINGS AND CAUTIONS

Statements in this manual preceded by the words WARNING or CAUTION and printed in italics are very important. We recommend you take special notice of these during service or repair.

WARNING

Means there is the possibility of personal injury to yourself or others.

CAUTION

Means there is the possibility of damage to the CAMCO unit.

OIL SEAL REMOVAL

The only repair possible without disassembly of the index drive is replacement of oil seals. To remove oil seals, drill a number of holes into the case of the seal. The seal may then be removed with a pointed tool. Be sure to remove all metallic chips created during the drilling of removal holes. A new seal may be installed as outlined in the "Oil Seal Installation Recommendations" section of the "General Service Manual".

SPARE PARTS KIT

CAMCO offers a Spare Parts Kit for all CAMCO index drive models CAMCO builds. These kits include oil seals, bearings, shims and cam followers. These are components that will most likely require replacement during repair of your index drive.

A complete list of components supplied in the Spare Parts Kit can be found in the parts list located in the rear of this manual. The asterisk behind the item number indicates those parts supplied with the Spare Parts Kit.

BEFORE STARTING

Before starting disassembly of your CAMCO unit you should read and review the following instructions. These provide important information on parts and procedures necessary to successfully complete your repair.

Comply with all Warnings and Cautions.

Read the "Trouble Shooting Guide" section of your "General Service Manual" before disassembling CAMCO units. CAMCO recommends returning defective equipment for inspection and repair whenever possible.

CAMCO uses Loctite to secure all screws and setscrews. If you encounter a fastener that is difficult to remove, apply heat to the screw and remove while still warm.

DISASSEMBLY

1. GENERAL

- A. Remove all accessory equipment such as clutches, reducers, sprockets, etc. If equipped with a CAMCO Reducer, see disassembly instruction pertaining to this reducer prior to removal from unit.

2. CAM ACCESS PLUG AND LUBE REMOVAL

- A. To remove the plug (32), drill a hole into the plug.
- B. The plug may then be removed with a pointed tool. Be sure to remove all chips created during the drilling of removal holes.
- C. At this time the entire unit should be flushed with a solvent to remove grease from the cam compartment.

3. OPTIONAL STATIONARY OUTPUT SHAFT REMOVAL

- A. Remove the four screws (31).
- B. Tap optional stationary output shaft (24) free of housing (1).
- C. Remove quad ring (10) and o-ring (18) from stationary output shaft (24).

4. OPTIONAL OUTPUT SHAFT PLUGS REMOVAL

- A. To remove the optional output shaft plug (30), drill a hole into the plug.
- B. The plug may then be removed with a pointed tool. Be sure to remove all chips created during the drilling of removal holes.
- C. Insert a soft drive thru the output shaft and tap out plug (29).

5. OUTPUT SHAFT/FOLLOWER WHEEL REMOVAL

- A. Turn the unit over and remove the eight screws (20).
- B. Remove output bearing retainer (6) and shims (12) from housing (1).

NOTE: Keep shims (12) with retainer (6). You will be asked to reinstall or replace with the same shim thickness during assembly.

- C. Remove quad seal (9) from output bearing retainer (6).
- D. Remove follower wheel (2) from housing (1).
- E. Remove shims (11).

NOTE: Keep shims (11) with follower wheel (2). You will be asked to reinstall or replace with the same shim thickness during assembly.

6. OPTIONAL THRU HOLE TUBE REMOVAL

- A. Remove thru hole tube (8).
- B. Remove seal (25) from housing (1).

7. INSPECTION OF CAM FOLLOWERS

Inspect followers for damage or radial looseness. It should not exceed 0.001 inch. Do not confuse radial looseness with axial endplay. Endplay will be from 0.03 to 0.06 inch as a normal condition. If it exceeds 0.06 inch, it may require replacement.

NOTE: Generally, followers are replaced as added insurance against eventual failure.

8. FOLLOWER REMOVAL

- A. Apply heat to setscrews (26) and remove the setscrews while still warm.
- B. Threaded holes have been provided in the ends of the follower for ease of removal. Use a slide hammer or a simple self made pull tool. The self made pull tool consists of a short piece of round tubing large enough to clear the follower diameter and a small flat bar with a clearance hole large enough to insert a capscrew of equal thread size as the follower pull hole. Slip the tube over the follower, place the bar over the tube and thread the capscrew into the follower. Tightening the capscrew will remove the follower.
- C. Check the follower holes for roundness. These holes may be elongated due to overloads and jams.

9. OUTPUT SHAFT/FOLLOWER WHEEL BEARING REMOVAL

- A. Apply heat to screws (21) and remove the screws with washers (22) while still warm.
- B. Remove bearing (7) from follower wheel (2).

10. INPUT SHAFT/CAM REMOVAL

- A. Rotate the input shaft (4) and inspect all parts for wear or damage. Endplay in the input shaft is not permissible.
- B. Matchmark cartridges (5) relative to the housing (1). These must be reinstalled in the same side and position since they are eccentric.
- C. Drill out the roll pin from both bearing cartridges (5).

- D. Remove four screws (16) from one of the bearing cartridges (5).

- E. Tap on the opposite end of the input shaft (4) to loosen bearing cartridge (5). Remove the cartridge and shims (13).

NOTE: Keep shims with bearing cartridge. You will be asked to reinstall or replace with the same shim thickness during assembly.

- F. Remove four screws (16) from remaining bearing cartridge (5).
- G. Tap on the opposite end of the input shaft (4) to loosen bearing cartridge (5). Remove the cartridge and shims (13).

NOTE: Keep shims with bearing cartridge. You will be asked to reinstall or replace with the same shim thickness during assembly.

- H. Remove input shaft (4) from housing (1).

11. INPUT SHAFT/CAM DISASSEMBLY

- A. Use a wheel puller to remove bearing cones (14) from input shaft (4).
- B. Remove spacer (27) from input shaft (4).
- C. Place the input shaft vertically on an arbor press. Block cam (3) and press the input shaft out of the cam.

NOTE: This procedure can be accomplished by driving the input shaft out of the cam with a soft faced hammer if an arbor press is not available.

- D. Remove key (23) from input shaft (4).
- E. Remove input bearing cups (15) from cartridges (5) with a pulley puller, by prying, or drilling and tapping for jack screws.

ASSEMBLY

1. PRIOR TO ASSEMBLY

- A. Clean and deburr all parts before reassembling.
- B. Follow tightening torque and loctite recommendations as outlined in the "General Service Manual".

2. INPUT SHAFT/CAM REASSEMBLY

- A. Install key (23) on input shaft (4).
- B. Apply anti-seize lubricant to both input shaft (4) and the bore of cam (3).
- C. Preposition the cam on the shaft so that the keyway in the cam lines up with key (23).
- D. Use an arbor press to press the shaft into the cam.
- E. Install spacer (27) on shaft (4).
- F. Apply anti-seize lubricant to both input shaft (4) and the bores of bearing cones (14).
- G. Use an arbor to press bearing cones (14) onto input shaft (4).

NOTE: CAMCO recommends heating the bearing cone with a heat gun, if available, prior to installation onto the shaft.

3. OUTPUT SHAFT/FOLLOWER WHEEL REASSEMBLY

- A. Apply anti-seize lubricant to both follower wheel (2) and the bore of bearing (7).
- B. Install bearing (7) onto follower wheel (2) until seated.
- C. Install screws (21) with washers (22) using loctite thread locking liquid as recommended in the "General Service Manual".

CAUTION: *Be sure to press the follower in straight as damage to the follower and wheel could occur if improperly aligned during installation.*

- D. Align the notch on the stud of follower (19) with the tapped hole for setscrew (26). Press in the follower using an arbor press.

NOTE: 1/2 inch diameter followers must be pressed in until the face of the follower is 0.522 inch above the face of follower wheel (2).

- E. Install set screw (26) using loctite thread locking liquid as recommended in the "General Service Manual".
- F. Install remaining followers (19) in the same manner.

4. INSTALLING NEW BEARING CUPS

- A. Coat the outside of bearing cups (15) and the bores of cartridges (5) with an anti-seize lubricant.
- B. Use an arbor to press the bearing cups into the cartridges.

5. SETTING INPUT SHAFT/CAM BEARING PRELOAD

- A. Position housing (1) on a work bench with the bore for plug (32) facing down and the bore for follower wheel (2) toward you.
- B. Install one cartridge (5) in the same side and position as disassembled (See matchmark instructions of Output Shaft/Follower Wheel Removal). Be sure to install the same exact shims or equivalent thickness as was removed during disassembly.
- C. Install and tighten screws (16).
- D. Insert the input shaft/cam (4) into housing (1) so that orientation of shaft is the same as before disassembly.
- E. Install remaining cartridge (5) in the same position as disassembled (See matchmark instructions of Output Shaft/Follower Wheel Removal). Be sure to install the same shims or equivalent thickness as was removed during disassembly.
- F. Install and tighten screws (16).

- G. Rotate the shaft and check preload. There should be no endplay and a small amount of drag should be felt from preloading the bearings. Add or remove shims as necessary to obtain this condition. In rare instances it may be necessary to remachine the cartridge if all shims have been removed and endplay still exists.

NOTE: The same amount of shims (13) should be added or removed from both cartridges (5) to retain its position in housing (1).

6. OUTPUT SHAFT/FOLLOWER WHEEL INSTALLATION

- A. Position housing (1) on a work bench with the bore for plug (32) facing down and the bore for follower wheel (2) toward you.
- B. Rotate input shaft/cam (4) until the dwell portion of the cam is downwards (facing the bore for the follower wheel).
- C. Install the same exact shims (11) or equivalent thickness as was removed during disassembly.
- D. Place the output shaft/follower wheel (2) on the work bench with followers (19) facing down.
- E. Inspect the face of output shaft/follower wheel (2). Locate the holes for bolts (21). One of these holes has an extra hole right next to it. This extra hole must be located at the 6 o'clock position when the output shaft/follower wheel is installed in housing (1).
- F. Insert the output shaft/follower wheel (2) down thru the opening of housing (1).
- G. Install output bearing retainer (6) with shims (12). Be sure to install the same exact shims as determined in step 5.
- H. Install and tighten screws (20).

7. SETTING CAM

CAUTION: *This mechanism is designed to operate with adjacent followers in close contact along their entire width with the surface of the cam during dwell period (Period where no follower motion is observed). Unless this condition is achieved by proper installation, the mechanism will not transmit its rated load, and furthermore, serious damage to the cam and output shaft will occur.*

- A. Apply "Prussian Blue" to the entire cam track.

IMPORTANT: *The following procedure is very important and can be difficult if not performed by trained and experienced serviceman.*

- B. Rotate the input shaft/cam (4) slowly with a small handcrank to ensure that:
 1. Both followers (19) are in contact with the cam rib in dwell. Look for a uniform bluing pattern.

If not, loosen screws (16) and rotate tops of cartridges (5) until both followers are in contact. Tighten screws (16).
 2. You do not encounter unusual resistance in motion. The bluing pattern should be fairly uniform from side to side during motion.

If a patch of bluing is worn off the outside of the cam rib on one side of the cam and not the other, remove cartridges (5) and shift shims (13) from one cartridge to the other to shift the cam 0.002 to 0.005 inches in the direction of the worn side. Do not overshift the cam or knocking will occur.

8ORDM SERIES

Service Manual

3. There should be no looseness in any dwell.

If there is, loosen screws (16) and rotate tops of cartridges (5) to slightly preload the loosest dwell. Tighten screws (16).

4. There should be even preload in different motions.

If not, remove output shaft/follower wheel (2) and adjust shims (11) to move the output shaft/follower wheel (2) in or out.

- C. Matchmark cartridges (5) with housing (1) to retain proper adjustment.

- D. Final assemble cartridges (5) as follows:

1. Remove one cartridge (5) and shims (13).
2. Apply Mobilith AW-2 Grease in bearing cup (15).
3. Install o-ring (28) on cartridge (5).
4. Install shims (13) on cartridge (5).
5. Apply a bead of silicone around the flange of bearing cartridge (5).
6. Apply a dab of silicone to the holes in housing (1) for screws (16).
7. Install cartridge (5), install screws (16), align matchmarks to obtain proper cam setting and tighten screws (16).
8. Remove opposite cartridge (5) and shims (13).
9. Apply Mobilith AW-2 Grease to bearing cone (15).
10. Install o-ring (28) on cartridge (5).

11. Install shims (13) on cartridge (5).

12. Apply a bead of silicone around the flange of bearing cartridge (5).

13. Apply a dab of silicone to the holes in housing (1) for screws (16).

14. Install cartridge (5), install screws (16), align matchmarks to obtain proper cam setting and tighten screws (16).

15. Drill a hole through each cartridge (5) and into housing (1) and install a roll pin to prevent the cartridge from rotating.

8. OIL SEAL INSTALLATION

- A. Install new oil seals (17) as described in the "General Service Manual".

9. OPTIONAL THRU HOLE TUBE INSTALLATION

- A. Position thru hole tube (8) in the bore of housing (1) and tap into output shaft/follower wheel (2).

NOTE: One end of the thru hole tube (8) has a larger OD. The larger OD must be installed into output shaft/follower wheel (2).

- B. Install new oil seal (25) into housing (1) as described in the "General Service Manual".

10. OPTIONAL STATIONARY OUTPUT SHAFT INSTALLATION

- A. Install quad ring (10) and o-ring (18) on stationary output shaft (24).
- B. Tap optional stationary output shaft (24) into housing (1).
- C. Install the four screws (31).

11. OPTIONAL OUTPUT SHAFT PLUGS INSTALLATION

- A. Position the optional output shaft plug (30) in the bore of housing (1) and tap into place until flush with the housing surface.
- B. Position plug (29) in its bore of housing (1) and tap into place until flush with the housing surface.

12. LUBRICATION

- A. Fill the cam chamber of housing (1) (level with the sidewalls) with Mobilith AW-2 grease.
- B. Position the two plugs (32) in their bores of housing (1) and tap into place until flush with the housing surface.

80RDM SERIES

Service Manual

HOW TO ORDER PARTS

Please refer to parts list shown in this manual. This parts list is for a standard index drive. If you feel your unit is nonstandard or you are in doubt, you should contact CAMCO Customer Service at (312) 459-5200 and request a Bill of Material for your specific unit based on serial number. CAMCO maintains records on all units for a period of ten years.

You may order parts per the standard Bill of Material even if your unit is nonstandard. CAMCO's order entry people will review the closed order file based on the following information and supply you with the correct part.

REQUIRED INFORMATION

1. Original purchase order number (if available)
2. Customer name (original purchaser of drive)
3. Model number (located on name plate)
4. Serial number (located on name plate)
5. Approximate date of purchase.

TO ORDER PARTS contact CAMCO "Order Entry Department" Wheeling, Illinois
Phone (847) 459-5200 or FAX #847-459-3064

- A. Describe the parts required and the 14 digit part number as listed in the Standard Bill of Materials or a Special Bill of Materials pertaining to your unit. State if you are using a Standard or Special bill of material.
- B. Give as much of the above required information as possible.

ON WARRANTY


Replacement parts CAMCO will send freight prepaid via practical means.

CAMCO will issue a "Returned Material Authorization Number" (RMA#) for the return of defective parts for inspection. CAMCO will bill customer for repair parts. When inspection of returned parts has been completed and determined to be a warranty problem, CAMCO will issue a credit to the customer for the repair parts and freight charges.

ON NON-WARRANTY

Replacement or spare parts, with approved credit, are sent F.O.B. our plant Wheeling, Illinois.

80RDM



PARTS LIST FOR 80RDM INDEX DRIVE (STANDARD CONFIGURATION)

<u>ITEM NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	55D67120001002	HOUSING
	55C67853001002	HOUSING W/180SM ALT
2	55C66919014010	FOLLOWER WHEEL H16 FOLLOWERS
	55C66918034012	FOLLOWER WHEEL H20 FOLLOWERS
3	-----	CAM (SPECIFY NUMBER OF STOPS AND INDEX TIME, CONTACT CAMCO FOR ASSISTANCE)
4	55B66884007002	SHAFT INP DE (W/O REDUCER)
	55C67384007002	SHAFT INP DE (FOR REDUCER)
5	55B66894003002	CART MACH INP OPEN
6	55C66920000000	RETAINER OUTP BRG
7	86A67170000000	BRG KAYDON KD045XPOK
8	55A66959000000	TUBE, THRU HOLE
9	84A67143740000	QUAD RING MINN-R 353-525K
	84A67421740000	QUAD RING VITON (#Q4353-514AD)
	84C65421380000	OIL SEAL C/R 29540 NITRILE
	84A67422410000	OIL SEAL (METRIC) - VITON
10	84A67143480000	QUAD RING NITRILE (FOR STATIONARY OUTPUT ONLY)
11	55B67172018800	SHIM, 0.002 THK RETAINER
	55B67172028800	SHIM, 0.005 THK RETAINER
	55B67172038800	SHIM, 0.010 THK RETAINER
12	-----	CONSULT CAMCO FOR SHIM NUMBER
13	55B67159018800	SHIM INP
	55B67159028800	SHIM INP
	55B67159038800	SHIM INP
	55B67159048800	SHIM INP
14	86D07328090021	BEARING CONE LM 12749
15	86D07328090022	BEARING CUP LM12711
16	95A33040180000	SHCS M6 X 18
17	84C65421040000	OIL SEAL C/R 7915 NITRILE
	84C65421050000	METRIC OIL SEAL C/R 7916
18	84A64420660000	O-RING 70MM X 3 MM NITRILE (FOR STATIONARY OUTPUT ONLY)
19	82C33150010003	CAM FLWR H20
	82C33150060003	CAM FLWR H20
20	95A51910310000	S.H.C.S. M4 X 12
21	95A33040040000	S.H.C.S. M5 X 12
22	95A26021210000	WASHER FLAT 3/16 VLIER 6018
23	018K200	KEY 0.1875 SQ. X 2.00
24	55C66969000000	SHAFT STATIONARY OUTPUT (OPTIONAL)
25	89B67859009100	MTG PLT 180SM ON 450RDM

80RDM SERIES

Service Manual

PARTS LIST FOR 80RDM CONTINUED

<u>ITEM NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
26	95A33041120000	S.S.S. CUP PT. M4 X 8 (USED WITH H16 FOLLOWERS)
	95A33041190000	S.S.S. CUP PT. M5 X 8 (USED WITH H20 FOLLOWERS)
27	55A67131009000	SPACER INPUT, 450RDM
28	84A64420410000	O-RING 60MM X 2.5 MM NITRILE
29	5MA52057000000	BORE PLUG 2.756
30	55A67134000000	BORE PLUG, 3.937 BORE
31	95A33040180000	SHCS M6 X 18

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

TABLE OF CONTENTS

INTRODUCTION.....	2
WARNING AND CAUTIONS.....	2
OIL SEAL REMOVAL.....	2
SPARE PARTS KIT.....	2
DISASSEMBLY	3
REMOVAL OF OUTPUT/FOLLOWER WHEEL	3
INSPECTION & REMOVAL OF CAM FOLLOWERS	3
INPUT SHAFT/CAM REMOVAL	4
PRIOR TO REASSEMBLY.....	5
ASSEMBLY	5
ASSEMBLING INPUT SHAFT	5
ASSEMBLING OUTPUT SHAFT.....	5
SETTING CAM.....	6
HOW TO ORDER PARTS	8
EXPLODED PARTS DRAWING.....	9
PARTS LIST	10

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

INTRODUCTION

This service manual pertains to the disassembly and assembly of CAMCO's RDM Series Index Drives models 601RDM, 902RDM, 1305RDM, & 1800RDM.

The manual is to be used in conjunction with the General Service Manual which describes the lubrication and general maintenance of CAMCO Index Drives.

An exploded view of your specific Index Drive is included in this manual. Also included is a complete Bill of Materials for your convenience in identifying and ordering spare or replacement parts.

Some users of Index Drives have the facilities and trained personnel to accomplish service repair. You must determine the extent to which intricate servicing should be done in your own facility. When in doubt, CAMCO recommends that CAMCO trained servicemen make the repairs.

WARNINGS AND CAUTIONS

Statements in this manual preceded by the words **WARNING** or **CAUTION** and printed in italics are very important. We recommend you take special notice of these during service or repair.

WARNING

Means there is the possibility of personal injury to yourself or others.

CAUTION

Means there is the possibility of damage to the CAMCO unit.

OIL SEAL REMOVAL

The only repair possible without disassembly of the indexer is replacement of oil seals. To remove oil seals, drill a number of holes into the case of the seal. The seal may then be removed with a pointed tool. Be sure to remove all metallic chips created during the drilling of removal holes. A new seal may be installed as outlined in the "Oil Seal Installation Recommendations" section of the "General Service Manual".

SPARE PARTS KIT

CAMCO offers a Spare Parts Kit for all CAMCO index drive models CAMCO builds. These kits include oil seals, bearings, shims and miscellaneous hardware. Camfollowers are sold separately. These are components that will most likely require replacement during repair of your index drive. CAMCO recommends a Spare Parts Kit be purchased and kept on hand prior to the disassembly of your CAMCO drive.

A complete list of components supplied in the Spare Parts Kit can be found in the parts list located in the rear of this manual. The asterisk behind the item number indicates those parts supplied with the Spare Parts Kit. See page 16 for additional spare parts information.

BEFORE STARTING

Before starting the disassembly of your CAMCO unit you should read and review the following instructions. These provide important information on parts and procedures necessary to successfully complete your repair.

Comply with all Warnings and Cautions.

Read the "Trouble Shooting Guide" section of your "General Service Manual" before disassembling CAMCO units. CAMCO recommends returning defective equipment for inspection and repair whenever possible.

DISASSEMBLY

1. REMOVE ALL ACCESSORY EQUIPMENT such as clutches, reducers, sprockets, etc. If equipped with a CAMCO R250 Reducer see disassembly instructions manual 0079 pertaining to this reducer prior to removal from the unit.
2. DRAIN OIL AND FLUSH UNIT with flushing solvent. Retain any chips or broken pieces you may find. These may aid in diagnosis.
3. REMOVE BOTTOM COVER.
4. REMOVAL OF OUTPUT SHAFT.
 - A. Remove the capscrews holding the large output bearing retaining ring.
 - B. Drive the two dowel pins through the retaining ring and housing with an undersize punch.
 - C. Lift the output/follower wheel from the housing. Save the retaining ring shims for later installation.



Fig.1 Output shaft removal

5. FOLLOWER INSPECTION.

Inspect followers for damage or radial looseness. It should not exceed .001 inch. Do not confuse radial looseness with axial endplay. Endplay will be from .03" to .06" as a normal condition. If it exceeds .06 it may require replacement.

NOTE: Generally, followers are replaced as added insurance against failure later.




Fig.2 Inspecting for radial looseness

6. FOLLOWER REMOVAL.

Followers can be removed at this stage.

- A. Remove the setscrews. Apply heat to the setscrews holding the follower studs and remove while still warm.
- B. Threaded holes have been provided in the ends of the follower for ease of removal. Use a slide hammer or a simple self-made pull tool. The self-made pull tool consists of a short piece of round tubing, large enough to clear the follower diameter and a small flat bar with a clearance hole large enough to insert a capscrew of equal thread size as the follower pull hole. Slip the tube over the follower, place the bar over the tube and thread a capscrew into the follower. Tightening the capscrew will remove the follower.



Fig.3 Follower pull tools.

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual



Fig.3A Follower pull tools in use.

7. CHECK THE FOLLOWER HOLES.

Check the follower holes for roundness. These holes may be worn out due to overloads. The holes should be round to within .0005 to permit reuse of the follower wheel.

8. OUTPUT SHAFT DISASSEMBLY.

- A. Turn output shaft over and tap on back side of retaining ring, alternating from side to side until the retaining ring is free of the output/follower wheel.
- B. Remove the main bearing from the output/follower wheel.
 - 1) Remove the bearing retaining capscrews and washers.
 - 2) From the top side of the output, place a small aluminum bar against the inside face of the bearing and tap with a hammer. Alternate from side to side to prevent cocking until the bearing is free of the output/follower wheel.



Fig .4. Removing output bearing.

9. INPUT SHAFT / CAM REMOVAL.

NOTE: The output shaft must be removed prior to input shaft removal.

- A. Rotate the input shaft and inspect all parts for damage or wear. Endplay in the input shaft is not permissible.
- B. Remove all input bearing cartridge capscrews.
- C. Tap on the end of the input shaft to drive the opposite cartridge from the housing. Then drive the shaft in the opposite direction for removal of the other cartridge.

NOTE: Keep shims with their respective cartridges. You will be asked to reinstall or replace with the same shim thickness during assembly.

- D. Remove the input shaft/cam assembly from the housing.



Fig. 5 Removing input shaft assembly

- E. Use a wheel puller to remove the bearing cones from the input shaft.
- F. Remove the cam locknuts with a spanner wrench. Be sure to bend the washer locking tangs away from the nut prior to removal, if applicable.
- G. Use an arbor press to remove the cam from the input shaft. Use caution not to damage the parts. If an arbor press is not available you may drive the shaft out by tapping on the end of the shaft with a soft face.




Fig. 6 Pressing out camshaft

10. REMOVE THE INPUT BEARING CUPS

Remove the input bearing cups from the cartridges with a pulley puller, by prying or by drilling and tapping for jack screws.

ASSEMBLY

PRIOR TO REASSEMBLY

Clean and deburr all parts before reassembly.

Follow tightening torque and Loc-Tite recommendations as outlined in the "General Service Manual".

- 1. Use an arbor to press the bearing cups into the cartridges. Coat the outside of the cup and the bore of the cartridge with an anti-seize lubricant prior to pressing. Fill cavity of cartridges with bearing grease recommended in the "General Service Manual".

2. ASSEMBLING INPUT SHAFT.

- A. Use arbor to press the cam onto the shaft. Be sure key is installed into the shaft first. Apply anti-seize lubricant to shaft and bore prior to pressing. If a heat gun is available it is recommended that the bore of the cam be heated prior to pressing.
- B. Use a spanner wrench to install the cam locknuts. Adjust nuts to center cam on shaft.



Fig. 7. Centering cam on shaft

- C. Use an arbor to press bearing cones onto shaft. Coat shaft and bearing bore with anti-seize lubricant prior to pressing. If a heat gun is available it is recommended that the bore of the bearing be heated prior to pressing.
- D. Install the input cartridges. Be sure to install the same exact shims or equivalent height as was removed in disassembly Step 9C.
- E. Tighten cartridge mounting screws.
- F. If endplay exists remove an equal amount of shims from each side until there is a small amount of drag from preloading the bearings. In rare instances it may be necessary to re-machine the cartridges if all shims have been removed and endplay still exists.

3. ASSEMBLING OUTPUT SHAFT.

- A. Install the large bearing cones on the output shaft. Coat the bore of the cone with an anti-seize lubricant prior to installation. Tap in place with a hammer and aluminum bar. Place the bar against the inner face and tap with hammer. Alternate from side to side to avoid binding until the bearing is fully seated on the output/follower wheel.

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

- B. Install the bearing retainer capscrews and washers. Use torque and Loc-Tite recommendations from the "General Service Manual".

- C. Install new followers with an arbor press.

CAUTION: Be sure to press the followers in straight as damage to the follower and wheel could occur if improperly aligned during installation. Be sure that the notches are aligned with the setscrew holes.




Fig. 8 Pressing in new followers

- D. Install the setscrews with double-notch followers, the cone point setscrews lock into the "V" notch. The cup point setscrews lock against the flat single-notch followers, use an oval point setscrew. Be sure to use Loc-tite thread locking liquid as recommended in the "General Service Manual".
- E. Coat the inside of the bearing retainer ring and the outside of the main output bearing with anti-sieze lubricant. Place the bearing retainer ring over the output from the topside of the output/follower wheel and tap, alternating from side to side until the retainer is fully seated on the bearing.
- F. Replace the shims removed in disassembly step 4C.
- G. Place cam in dwell position, keyway pointing rearward.
- H. Insert output/follower wheel into housing with dowel holes in housing in line with retainer.
- I. Loosely install the bearing retainer capscrews.
- J. Install only one of the dowel pins through the retainer ring into the housing.

4. SETTING THE CAM.

CAUTION: This mechanism is designed to operate with adjacent followers in close contact along their entire width, unless this condition is achieved by proper installation, the mechanism will not transmit its rated load, and serious damage to the cam and output shaft will occur.

- A. Place the unit on end or its side so both the output side and the bottom opening are accessible.
- B. Place the cam in dwell, keyway facing rearward.
- C. While pivoting on the one dowel pin, rotate the output towards the input shaft as much as the clearance holes for the mounting capscrews will allow.
- D. Shift the cam axially until two adjacent followers are in full contact with the cam rib. This will also require adjustment of the output retaining ring along with axial adjustment of the cam.
- 1) If there is a gap at the root of the follower the cam should be shifted toward the follower.
 - 2) If there is a gap at the tip of the follower the cam should be shifted away from the follower.




Fig.9 Shifting cam for proper alignment

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

- E. Apply "Prussian Blue" to entire cam track.
- F. Rotate the camshaft slowly with a small handcrank to ensure that:
 - 1) Both rollers are in contact with the cam rib in dwell. Look for uniform blueing pattern.
 - 2) The follower is free when it is in the center of the crossover track.
 - 3) You do not encounter unusual resistance in motion. The blueing pattern should be fairly uniform from side to side during motion. If a patch of blueing is worn off the outside of the cam rib on one side of the cam and not the other, shift the cam a .002 to .005 inches in the direction of the worn side. Do not overshift the cam or knocking will occur.
 - 4) The cam blueing should never be worn off the lead-in or exit edges of the cam ribs. This would indicate that the cam is not adjusted properly.
 - 5) There should be no looseness in any dwell. If there is looseness adjust the output bearing retainer to slightly preload the loosest dwell.
- G. Tighten the locknuts and secure with Loc-Tite #242 as specified in the "General Service Manual". If lockwashers are used on your model, bend the tangs over the nut to insure locking.
- H. Tighten the output retaining ring capscrews.
 - I. Drill and ream the remaining hole in the output retaining ring to accept the next larger dowel pin. Install new dowel.
- 8. REINSTALL THE BOTTOM COVER. Apply "General Electric Silicone Rubber RTV-6" to the sealing surfaces of the housing and cover. Place the gasket on the housing and place cover over the gasket. Install and tighten capscrews.
- 9. GREASE PACK THE MAIN OUTPUT BEARING with lubricant specified in the "General Service Manual".
- 10. INSTALL NEW OIL SEALS as described in the "General Service Manual".
- 11. FILL THE INDEX WITH THE RECOMMENDED OIL to level indicator. See "General Service Manual". Too high an oil level will cause no damage. Too low a level may result in unit failure.




Figure 10 Tighten cam locknuts

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

HOW TO ORDER PARTS

Please refer to parts list shown in this manual. This parts list is for a standard Index Drive. If you feel your drive is nonstandard or you are in doubt you should contact CAMCO Customer Service at (847) 459-5200 and request a Bill of Materials for your specific unit based on serial number. CAMCO maintains records on all units for a period of ten years.

You may order parts per the standard Bill of Material even if your unit is nonstandard. CAMCO's order entry department will review the closed order file based on the following information and supply you with the correct part.

REQUIRED INFORMATION

1. Original purchase order number (if available)
2. Customer name (original purchaser of drive)
3. Model number (located on name plate)
4. Serial number (located on name plate)
5. Approximate date of purchase.

TO ORDER PARTS contact CAMCO "Order Entry Department" Wheeling, Illinois

Phone (847) 459-5200 or Fax (847) 459-3064

- A. Describe the parts required and the 14 digit part number as listed in the Standard Bill of Materials or a Special Bill of Materials pertaining to your unit. State if you are using a Standard or Specific bill of material.
- B. Give as much of the above required information as possible.

ON WARRANTY

CAMCO will send replacement parts freight prepaid via most practical mean.

CAMCO will issue a "Returned Material Authorization Number" (RMA#) for the return of defective parts for inspection. CAMCO will bill customer for repair parts. When inspection of returned parts has been completed and determined to be covered under warranty, CAMCO will issue a credit to the customer for the repair parts and freight charges. Camco standard warranty is defined in Camco's "Terms and Conditions".


ON NON-WARRANTY

Replacement or spare parts, with approved credit, are F.O.B. our plant Wheeling, Illinois.

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

601RDM, 902RDM, 1305RDM & 1800RDM



601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

PARTS LIST FOR 601RDM INDEX DRIVE (STANDARD CONFIGURATION)

ITEM NO.	PART NUMBER	DESCRIPTION
1	51D51194001002	Housing
2	51C38781014012	Follower wheel 12 hole
.....	51C38781024016	Follower wheel 16 hole
3	Cam, (specify number of stops and Index time, contact camco for Assistance, order in matched sets)
4	51C37687007002	Input shaft (w/o red or w/180SM)
.....	51C52700007002	Input shaft (for 7200C)
.....	51C65588007002	Input shaft (for 180SM/180-IOC)
5	51C51099003001	Cartridge, input
6	51C37690000000	Bearing retainer
7	86A27251000000	Bearing
8	51A52302000000	Tube,through hole
9	51B52264000000	Cover, bottom
10*	84D07329780000	Oil seal C/R 64993
11*	84D07329340000	Oil seal C/R 19745
12*	51B27248018800	Shim, .002
*	51B27248028800	Shim, .005
*	51B27248038800	Shim, .010
*	51B27248048800	Shim, .015
13	95A33001010000	Sight plug 3/8-18
14*	51B52278018800	Shim, .002
*	51B52278028800	Shim, .005
*	51B52278038800	Shim, .010
15*	86D07328120021	Bearing cone LM11949
*	86D07328070021	Bearing cone A6075
*	86D07328210021	Bearing cone 17119
16*	86D07328120022	Bearing cup LM11910
*	86D07328070022	Bearing cup A6157
*	86D07328210022	Bearing cup 17244
17	95A26000390000	S.H.C.S. 1/4-20 x 5/8
18*	84D07329080000	Oil seal C/R 7443
*	84D07329180000	Oil seal C/R11878
19	Not used on 601RDM
20	95A26003140000	B.H.C.S. 10-24 x 3/8
21	95A33003010000	Magnetic plug
22	95A33000010000	Air vent 3/8-18
23	95A26009050000	Locknut
24	95A26010050000	Lockwasher
25	82C33150020003	Cam follower
26*	95A26012070000	S.S.S. oval 10-24 x 3/8
27	95A26000430000	S.H.C.S. 1/4-20 x 1 1/4
28	95A26000530000	S.H.C.S. .31 x .62
29	99A27266000000	Flat washer
30	025K200	Key .250 SQ. X 2.00
31	Not used on 601RDM
32	51C39452000000	Stationary output shaft
33*	84A54015000000	O-ring 2-234
34	Not used on 601RDM
35	26B01051049000	Spacer output
36*	99A44547070000	Service manual for RDM
37*	99A44547010000	General service manual

* Indicates parts supplied with Spare Parts Kit #SPK601RDM

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

PARTS LIST FOR 902 RDM INDEX DRIVE (STANDARD CONFIGURATION)

ITEM NO.	PART NUMBER	DESCRIPTION
1	56D59101001002	Housing Standard
.....	56C44335001002	Housing W/ Center Post/Tooling
.....	56D41866001002	Housing W/PI Mounting Holes
.....	56C38728001002	Housing W/Stationary Center Post
2	56C38768014012	Follower Wheel 12 Hole H32
.....	56C38768024016	Follower Wheel 16 Hole H32
3	Cam, (Specify Number Of Stops And
.....	Index Time, Contact Camco For
.....	Assistance, Order In Matched Sets)
4	56C38713007002	Input Shaft (No Reducer)
.....	83D36422007002	Input Shaft (For R250)
.....	56C39230007002	Input Shaft (For 25GED)
.....	56C63374007002	Input Shaft (For R225)
.....	56D63506007002	Input Shaft (For R225 W/IOC)
.....	56C51857007002	Input Shaft (For R260)
.....	56D61647007002	Input Shaft (For R260 W/ 20 DHL)
.....	83D47856007002	Input Shaft (For R250 Dual C/L)
5	56C36428003021	Cartridge Open (Inp)
6	56C23495009300	Retainer Bearing
7	86A24320000000	Bearing
8	Not Used On 902RDM
9	56B35134009600	Cover, Bottom
10*	84D07329860000	Oil Seal C/R 95052
11*	84D07329500000	Oil Seal C/R 27280
12*	56B36432018800	Shim, .002
*	56B36432028800	Shim, .005
*	56B36432038800	Shim, .010
13	95A33001010000	Sight Plug 3/8-18
14*	56C36423018800	Shim, .002
*	56C36423028800	Shim, .005
*	50B06038028800	Shim, .005
*	56C36423038800	Shim, .010
15*	86A22882000021	Bearing Cone Lm67049
16*	86A22882000022	Bearing Cup Lm67010
17	95A26000390000	S.H.C.S. 1/4-20 X 5/8
18	84D07329180000	Oil Seal C/R11878
19	Not Used On 902RDM
20	95A26015220000	H.H.C.S. 10-24 X 1/2
21	95A33003010000	Magnetic Plug
22	95A33000010000	Air Vent 3/8-18
23	95A26009070000	Locknut
.....	95A26009080000	Locknut
24	Not Used On 902RDM
25	82C33150040003	Cam Follower
26*	95A26012130000	S.S.S. Oval Pt 1/4-20 X 3/8
27	95A26000580000	S.H.C.S. 5/16-18 X 1 1/2
28	95A26016450000	S.H.C.S. 3/8-24 X 3/4
29	99A24322000000	Heavy Duty Flat Washer
30	031K300	Key .3125 Sq. X 3
31	95A33033170000	Retaining Ring 5160-125
32	56L26076009540	Stationary Output Shaft
.....	56C58129009540	Stationary Output Shaft For 10.50 Mounting
33*	99A26350000000	O Ring Parker #236
*	84A56357000000	O-Ring 2-155 Buna N
*	84A36425000000	O-Ring Parker #136
34	56C63181009100	Mounting Plate (For R225)
.....	56D36427003021	Mounting Plate (For R250)
.....	80C39416009100	Mounting Plate (For Red)
.....	80C51855000000	Mounting Plate (For R260)
35	Not Used On 902 RDM
36*	99A44547070000	Service Manual-RDM
37*	99A44547010000	General Service Manual

* Indicates parts supplied with Spare Parts Kit #SPK901RDM

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

PARTS LIST FOR 1100RDM INDEX DRIVE (STANDARD CONFIGURATION)

<u>ITEM NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1.....	H3G83982001002	Housing
2.....	H3D83808034010	Follower wheel (10 hole, 1.25" followers)
2.....	H3D83994024010	Follower wheel (10 hole, 1.50" followers)
2.....	H3D83808014012	Follower wheel (12 hole, 1.25" followers)
2.....	H3D83994014012	Follower wheel (12 hole, 1.50" followers)
2.....	H3D83808024016	Follower wheel (16 hole, 1.25" followers)
2.....	H3D83996014018	Follower wheel (18 hole, 1.00" followers)
2.....	H3D83808044018	Follower wheel (18 hole, 1.25" followers)
2.....	H3D83996024020	Follower wheel (20 hole, 1.00" followers)
2.....	H3D83996034024	Follower wheel (24 hole, 1.00" followers)
3.....		Cam (specify number of stops and index period. Contact IMC for assistance)
4.....	H3D83805007002	Input Shaft (without reducer)
4.....	H3D83993007002	Input Shaft (for 7300C reducer)
4.....	H3D84091007002	Input Shaft (for KH47 reducer)
5.....	H3C83803003002	Input Cartridge
5.....	84B60170140000	O-Ring 2-160
6.....	09C29030009300	Bearing Retainer
6.....	95A26007670000	Dowel Pin 1/2 X 2-1/2
7.....	86A29059000000	Output Bearing
8.....		Not used on 1100RDM
9.....	H3B83807000000	Cover, Bottom
*10.....	84D74734900000	Oil Seal C/R 1150112
*11.....	84C65421670000	Oil Seal C/R 59010
*12.....	09B29064018800	Shim .002 (Output)
*12.....	09B29064028800	Shim .005 (Output)
*12.....	09B29064038800	Shim .010 (Output)
13.....	95A33001020000	Sight glass 1/2-14
*14.....	H3B84022018800	Shim .002 (Input)
*14.....	H3B84022028800	Shim .005 (Input)
*14.....	H3B84022038800	Shim .010 (Input)
*15.....	86D07328360021	Bearing Cone 26885
*16.....	86D07328280022	Bearing Cup 26822
17.....	95A33040330000	SHCS M8 X 20 MM
*18.....	84C65421170000	Oil Seal C/R 15845
20.....	95A37940310000	HHCS M8 X 12
21.....	95A33003020000	Magnetic Plug
22.....	95A33000020000	Air Vent 1/2-14
23.....	95A26009100000	Locknut PN-10
24.....	95A26010100000	Lockwasher W-10
25.....	0570602601	Cam Follower F-100 (1.00" / H32)
25.....	0570602602	Cam Follower F-125 (1.25" / H40)
25.....	0570602603	Cam Follower F-150 (1.50" / H48)
*26.....	95A33041280000	SSS CUP PT M6 X 10
27.....	95A33040550000	SHCS M10 X 50
28.....	95A33040650000	SHCS M12 X 25
29.....	95A26021260000	Washer
30.....	050K425	Key 1/2 SQ.X 4 1/4
32.....	H3C84025000000	Stationary Center Post
34.....	80C83992009100	Mounting Plate (7300C Reducer)
34.....	80C84093009100	Mounting Plate (KH47 Reducer)
36.....	99A44547070000	Service Manual for RDM
37.....	99A44547010000	General Service Manual

* Indicates parts supplied with Spare Parts Kit #SPK1100RDM

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

PARTS LIST FOR 1305RDM INDEX DRIVE (STANDARD CONFIGURATION)

ITEM NO.	PART NUMBER	DESCRIPTION
1	57G41046001002	Housing
2	57C42229014012	Follower Wheel 12 Hole
.....	57C42229024016	Follower Wheel 16 Hole
3	Cam, (Specify Number Of Stops And Index Time, Contact Camco For Assistance, Order In Matched Sets)
4	57D40902007002	Input Shaft (W/O Reducer)
.....	57D42389007002	Input Shaft (For 7350C, 30DHL)
.....	57D43552007002	Input Shaft (For 7300C, 30DHL)
.....	57D43807007002	Input Shaft (For 7350C)
5	57C40930003002	Cartridge, Input
6	57D42236000000	Retainer Bearing
7	86A42226000000	Bearing
8	Do Not Use On 1305RDM
9	57B40937000000	Cover, Bottom
10*	84A41047000000	Oil Seal C/R 1450242
11*	84A41048000000	Oil Seal C/R 57510
12*	57B42238018800	Shim .002
*	57B42238028800	Shim .005
*	57B42238038800	Shim .010
13	95A33001020000	Sight Plug 1/2-14
14*	57B40958018800	Shim .002
*	57B40958028800	Shim .005
*	57B40958038800	Shim .010
15*	86D07328460021	Bearing Cone 45287
16*	86D07328460022	Bearing Cup 45220
17	95A26000700000	S.H.C.S. 3/8-16 X 7/8
18*	84D07329380000	Oil Seal C/R 21336
19	57B40938000000	Gasket, Bottom Cover
20	95A26002140000	HHCS 5/16-18 X 5/8
21	95A33003020000	Magnetic Plug
22	95A33000020000	Air Vent 1/2-14
23	95A26009140000	Locknut
24	95A41521140000	Lockwasher
25	82C10457060003	Cam Follower
26*	95A26005450000	S.S.S. Cup 1/4-20 X 1/2
*	95A26006210000	S.S.S. Cone 1/4-20 X 1/2
27	95A26001100000	S.H.C.S. 1/2-13 X 2 1/4
28	95A26001050000	S.H.C.S. 1/2-13 X 1
29	95A26021260000	Flat Washer 6002
30	062K475	Key .625 Sq. X 4.75
31	Not Used On 1305RDM
32	57C41192000000	Stationary Output Shaft
33	Not Used On 1305RDM
34	80C44620000000	Mounting Plate (For 7300C)
.....	80D44630000000	Mounting Plate (For 7350C)
35	Not Used On 1305RDM
36*	99A44547070000	Service Manual-RDM
37*	99A44547010000	General Service Manual

* Indicates parts supplied with Spare Parts Kit #SPK1305RDM

601RDM, 902RDM, 1305RDM, 1800RDM SERIES

Service Manual

PARTS LIST FOR 1800RDM INDEX DRIVE (STANDARD CONFIGURATION)

ITEM NO.	PART NUMBER	DESCRIPTION
1	H2G48562001002	Housing
2	H2D48544014012	Follower Wheel 12 Hole
.....	H2D48544024016	Follower Wheel 16 Hole
3	Cam, (Specify Number Of Stops And Index Time, Contact Camco For Assistance, Order In Matched Sets)
.....
4	H2D48524007002	Input Shaft (W/O Red)
.....	H2D48525007002	Input (Shaft For 7400C)
.....	H2D48731007002	Input Shaft (For 7500C)
.....	H2D50672007002	Input Shaft (For 7400C/400-IOC)
.....	H2D55014007002	Input Shaft (For 7500C/500-IOC)
5	H2C64443003002	Cartridge Input
6	H2D64003000000	Bearing Retainer
8	Not Used On 1800RDM
9	56B35134009600	Cover Bottom
10*	84A48576000000	Oil Seal 2050252
11*	84A48577000000	Oil Seal 75030
12*	H2B48578018800	Shim, .002
*	H2B48578028800	Shim, .005
*	H2B48578038800	Shim, .010
13	95A33001030000	Sight Plug 3/4-14
14*	H2B48579018800	Shim, .002
*	H2B48579028800	Shim, .005
*	H2B48579038800	Shim, .010
15*	86D07328600021	Bearing Cone 566
16*	86D07328600022	Bearing Cup 563
17	95A26000710000	S.H.C.S. 3/8-16 X1
18*	84D07329510000	Oil Seal C/R 27295
19	H2C48539000000	Gasket, Cover 1800RDM
20	95A26003140000	B.H.C.S. 10-24 X 3/8
21	95A33003060000	Magnetic Plug
22	95A33000030000	Air Vent 3/4-14
23	95A26009160000	Locknut Pn-16
24	95A41521160000	Lockwasher Wh-16
25	82C10457080003	Cam Follower Cfh 292
26*	95A26005470000	S.S.S. Cup Pt 1/4-20 X 3/4
27	95A26001300000	S.H.C.S. 5/8-11 X 2 1/2
28	95A26001260000	S.H.C.S..5/8-11 X 1 1/2
29	95A26021270000	Washer Flat 6003
30	075K650	Key .750 Sq X 6.50 Lg
31	H2D64002000000	Retaining Ring, 1800RDM Mach
32	H2C48734000000	Stationary Output Shaft
33	Not Used On 1800RDM
34	80D48720000000	Mounting Plate (For 7400C)
.....	80C48730009100	Mounting Plate (For 7500C)
35	Not Used On 1800RDM
36*	99A44547070000	Service Manual-RDM
37*	99A44547010000	General Service Manual

* Indicates parts supplied with Spare Parts Kit #SPK1800RDM

[illegible]



GLOBAL LOCATIONS

NORTH AMERICA

Corporate Headquarters

Auburn Hills, Michigan
Toll Free: 1.888.DESTACO
Marketing: marketing@destaco.com

Global Technology Center

Auburn Hills, Michigan
Tel: 1.248.836.6700
Customer Service: customerservice@destaco.com

Mt. Juliet, Tennessee
Tel: 1.888.DESTACO
Customer Service: customerservice@destaco.com

Wheeling, Illinois
Tel: 1.800.645.5207
Customer Service: camco@destaco.com

Red Wing, Minnesota (Central Research Laboratories)
Tel: 651.385.2142
Customer Service: sales@centres.com

ASIA

Bangkok, Thailand
Tel: +66-2-326-0812
Customer Service: info@destaco.com

Shanghai, China
Tel: +86-21-6081-2888
Customer Service: china@destaco.com

Bangalore, India
Tel: +91-80-41123421-426
Customer Service: india@destaco.com

EUROPE

Oberursel, Germany
Tel: +49-6171-705-0
Customer Service: europe@destaco.com

Sainte Florine, France
Tel: +33-4-73545001
Customer Service: france@destaco.com

Wolverhampton, United Kingdom
Tel: +44-1902-797980
Customer Service: uk@destaco.com

Sant Boi de Llobregat, Spain
Tel: +34-936361680
Customer Service: spain@destaco.com

Uithoorn, Netherlands
Tel: +31-297285332
Customer Service: benelux@destaco.com