

## Service Manual


# ROBOHAND | RPW Series



WARNING: This is a controlled document. It is your responsibility to deliver this information to the end user of the Destaco Robohand product. Failure to deliver this could result in your liability for injury to the user or damage to the machine. For copies of this manual, call your Customer Service Representative at 1.248.836.6700

## **RPW SERIES**

## Parallel Grippers | Maintenance and Assembly Procedure



Item Qty		Name
01	1	Body
03	2	Piston
04	2	Cap
05	2	Shaft
06	1	Gear Cover
07	1	Gear
09	2	Shaft, Piston
10	2	Shaft,Gear
20	2	Block, End W/ Target Holes
21	1	Bearing, Needle
22	1	Dowel Pin
23	1	Ball

NOTE: Contact the Robohand Sales Department for a complete spare parts list with order numbers and prices.

#### **Assembly Procedure**

- 1) Lubricate and install seals.
- 2) Install pistons and shafts."
- 3) Place piston caps and retaining rings
- into body
  4) Install tooling plates and shafts
  5) Place bearing, shaft, and gear\*\* into body and install cap and retaining
- ring.for sync. version:
  a) For disassembly, use magnet to pull gear out of body.
- b) Install 2 rack shafts with teeth facing syncing gear.

#### **Non-Synchronous Procedure**

- 1) Take RPW synchronous gripper and remove the retainer ring and gear cover.
- 2) Slide out dowel pin and bearing.
- 3) Remove gear from gripper. (a magnet is often very helpful in removing the gear.)
- 4) Replace the dowel pin, gear cover, and retainer ring. The gripper is now non-synchronous.




















## **RPW SERIES**


## Parallel Grippers | Maintenance and Assembly Procedure



Item	Qty	Name
01	1	Body
03	2	Piston
04	2	Cap
05	2	Shaft
06	1	Gear Cover
07	1	Gear
09	2	Shaft, Piston
10	2	Shaft,Gear
20	2	Block, End W/ Target Holes
21	1	Bearing, Needle
22	1	Dowel Pin
23	1	Ball

NOTE: Contact the Robohand Sales Department for a complete spare parts list with order numbers and prices.

## **Accessory Installation & Adjustment Instructions**



Install target as shown, install sensors as shown, adjust for proper end of stroke sensing.



















## **GLOBAL LOCATIONS**

### **NORTH AMERICA**

#### Corporate Headquarters

Auburn Hills, Michigan Toll Free: 1.888.DESTACO Marketing: marketing@destaco.com

#### Global Technology Center Auburn Hills, Michigan

Tel: 1.248.836.6700

Customer Service: customerservice@destaco.com

Mt. Juliet, Tennessee Tel: 1.888.DESTACO

Customer Service: customerservice@destaco.com

Wheeling, Illinois Tel: 1.800.645.5207

Customer Service: camco@destaco.com

Red Wing, Minnesota (Central Research Laboratories)

Tel: 651.385.2142

Customer Service: sales@centres.com

### ASIA

Bangkok, Thailand Tel: +66-2-326-0812

Customer Service: info@destaco.com

Shanghai, China

Tel: +86-21-6081-2888

Customer Service: china@destaco.com

Bangalore, India

Tel: +91-80-41123421-426

Customer Service: india@destaco.com

### **EUROPE**

Oberursel, Germany Tel: +49-6171-705-0

Customer Service: europe@destaco.com

Sainte Florine, France Tel: +33-4-73545001

Customer Service: france@destaco.com

Wolverhampton, United Kingdom Tel: +44-1902-797980 Customer Service: uk@destaco.com

Sant Boi de LLobregat, Spain

Tel: +34-936361680

Customer Service: spain@destaco.com

Uithoorn, Netherlands Tel: +31-297285332

Customer Service: benelux@destaco.com





